



Install 4" square posts 6 ft apart .

On the inside of each post, i.e. the side that faces the neighbouring post, install a stainless steel C channel that measures 1" x 1 1/2" x 1", such that the 1 1/2" dimension is fastened to the post

Cut a Qualita board to length, i.e. whatever the net spacing is between the posts, less 1/2" (for expansion) and drop it down between 2 C channels.

Add clips 2 ft apart, then drop the next board down. Continue to the top of the post. Add a screw at the top to keep everything fastened

It is advised to add a bead of clear caulking to the top-facing groove of each board to prevent debris that may accumulate from holding water that then freezes